



















BIOS SETUP UTILITY

Main AI Tweaker Advanced Power Boot **Tools** Exit

- ▶ ASUS D.C. Profile
- ▶ AI NET 2

ASUS EZ Flash 2
Express Gate [Auto]
Enter OS Timer [10 Seconds]
Reset User Data [No]

- ↔ Select Screen
- F4 Select Item
- Enter Go to Sub Screen
- F1 General Help
- F10 Save and Exit
- ESC Exit